

SCHNEIDER ALTIVAR 28 SETTINGS FOR MPCSV CONTROLLERS

Code	Default	MPCSV Setting	Site Setting
Menu I/O			
tCC	2C		
L12	rrS		
L13	PS2	PS2	
L14	PS4		
AIC	SAI		
CrL	4		
CrH	20		
AO	rFr		
Aot	0		
r2	SrA		
Add	1		
bdr	19.2		
Menu Drive DrC			
UnS		240	
FrS	50		
tUn	no		
tFr	60	50	
Uft	n	P	
brA	YES		
FrT	0		
SFr	4.0		
nrd	YES		
Atr	no	Yes	
OPL	YES		
IPL	YES		
StP	no		
FLr	no		
drn	no		
SdS	30		
FCS	no		

Code	Default	MPCSV Setting	Site Setting
MENU Settings SET			
LFr			
rP1	0		
ACC	3	1.5	
dEC	3	1.5	
AC2	5		
dE2	5		
LSP	0		
HSP			
ItH			
UFr	20		
SLP			
FLG	33		
IdC			
tdC	0.5		
JPf	0		
JOG	10		
rPG	1		
rIG	1		
FbS	1		
PIC	no		
SP2	10	50	
SP3	15		
SP4	20		
SP5	25		
SP6	30		
SP7	35		
Ftd			
Ctd			
ttd	100		
tLS	0.0		